

Stud Sensor Category



ZC62264

ZIRCON STUD SENSOR-SL

(UPC 042186 618983)

**Basic stud finder – “edge to edge” locator to ¾”-depth; wood or metal studs
“over the stud” alert for repositioning/calibration**



ZC62258

ZIRCON STUD SENSOR-PRO LCD

(UPC 042186 619799)

**Advanced stud finder – “edge to edge” locator to ¾”-depth or DEEP SCAN mode to 1-1/2”; wood or metal studs + “Wire Warning” for electrical
“over the stud” alert for repositioning/calibration**



ZC62244

ZIRCON STUD SENSOR-i520

(UPC 042186 605914)

MultiScanner® Pro Stud Finder with both “edge to edge” and “center” locator to ¾”-depth or DEEP SCAN mode to 1-1/2”;
wood or metal studs
Metal mode for detecting steel pipe up to 3” and copper to 1-1/2”
Find and trace electrical wiring
Auto calibration regardless of stud position

Specialty Sensor Category



ZC70079

ZIRCON BREAKER ID – BASIC

(UPC 042186 640694)

Identifies circuit breaker by inserting transmitter in a wall plug and scanning breaker panel.
Auto calibration



ZC74090

ZIRCON LEAK ALERT-WIFI

(UPC 042186 688818)

WiFi connected water detector sends alert to single or multiple e-mails using existing router
Emits loud (105dB) alarm for up to 8 hours



ZC70220

ZIRCON BREAKER ID – PRO KIT

(UPC 042186 701128)

Pro Kit with multiple connectors for the transmitter and single panel scanner